



ELDER
ENGINEERING (HERTS) LTD

City Park, Watchmead
Welwyn Garden City,
Hertfordshire AL7 1LT
☎ +44 (0)1707 325 513
🌐 www.elderengineering.co.uk

SERIAL NO: EWSTP

DRAWING NO EE 2538

INSTRUCTIONS

(EXPOSED WIRE) STANDARD TEST PIECE

- 1 The materials specifications and designs used in the production of your finished STP comply with the requirements for the routine testing of x-ray screening equipment as described in Section 3.3 of ECAC Doc. 30.
- 2 HANDLING – Your unit must be handled with care to avoid breakage. Always use both hands to move the unit. DO NOT pick up by individual corners. Remember that the metallic substances being retained are heavy objects and can create stress on the casing if not supported in a sensible manner.
- 3 CLEANING – The casing can be affected by certain chemicals therefore cleaning the unit must be carried out using either:-
 - A damp leather type cloth with water
 - Special acrylic anti-static cleaner available from: Elder Engineering (Herts) Ltd
- 4 LID RETAINING NUTS – The lid retaining nuts must only be screwed to a light finger tight strength. Do not use a screwdriver or apply any excessive strength. DO NOT OVERTIGHTEN
- 5 For enquiries regarding the correct use of your STP unit please contact the relevant authority in your country.

Signer on behalf of Elder Engineering (Herts) Ltd _____

QA Stamp

Date _____